



Assembly Tools:

- 1/4" Socket Metal Roof Screws
- 3/4" Socket - 1/2" Hardware
- 7/16" Socket 3/8" Hardware
- 7/16" Wrench 3/8" Hardware
- 3/4" Wrench Target Tension Nuts
- Mallet
- Hack saw
- 2ea 6'+ Ladders Roof Installation
- 3/16", 1/4", 3/8" drill bits.
- 1/2", 9/16", 1 3/8" Wood Drill bits

Cut List:

- 5ea 2" x 4" x 38" PT Studs
- 2ea. 2" x 4" x 63 1/4" PT Headers
- Attach with 3 1/2" Deck Screws